

Mounting elements	appropriate to	wall	ceiling	floor
hanging loops/ eyebolts Wall: We rivet two hanging loops on the backside of the frame so that the mirror can be easily hanged on the hooks or nails. Ceiling: We put four hanging loops or river nuts incl. eyebolts to hang the mirror upside down from the ceiling.		X	X	
Z-profile Wall: The lower part of the z-profile is screwed to the wall, the mirror is then set on the z-profile and fixed with the upper part. This method is especially suitable if more mirrors are being mounted side by side. Ceiling: Two persons are necessary if mounting the mirror onto the ceiling with z-profile.		X	X	
L-profile / U-profile L-Profile: With a bit of distance from the ceiling the L-profile is screwed to the wall. The mirror is then lifted in an inclined way and put down on the L-profile. U-Profile: The U-profile is screwed to the wall, onto the ceiling or to the ground. The U-profile can be also stuck with a double-sided adhesive tape. The mirror is then put inside of the U-profile and finally screwed or stuck together with the U-profile.		X	X	X
connecting clips/rivet nuts In order to connect more mirrors together and achieve a big surface, we recommend connecting clips, which screw two mirrors together. We can also set rivet nuts M5, M6 and M8 in order to simplify another methods of mounting.		X	X	X